

BOOST POLY WHEEL GUARD INSTALLATION

For Benno® Boost

COMPATIBILITY

BOOST EVO 1,2,3,4,5,6


FOR BOOST **EVO**LUTION FINDER GO TO:
BENNOBIKES.COM/BOOST/EVOLUTION

EVO (evolution) replaces model years and refers to design generations.


READ CAREFULLY BEFORE INSTALLATION AND USAGE. TO BE INSTALLED BY MECHANIC AT AUTHORIZED BENNO DEALER.

IMPORTANT: *Notes to mechanic:* See Instructions. Install Benno Boost Poly Wheel Guards only on compatible Benno Boost models in combination with selected Utility Rear Racks. Use only original (included) hardware and pre-drilled holes and fittings. Do not attach Poly Wheel Guards to damaged bikes or racks. Do not modify wheel guards, racks or bikes, change position or drill new holes as this will void any warranties and/or claims for liability.

Notes to owner: Periodically check to make sure all bolts and Velcro straps remain tight as vibrations may loosen them. Ensure that either Benno Wheel Guards or Utility Pannier Bags remain on the bike while carrying passengers.



Included: M8 Short 16mm Short Spacer



benno

WWW.BENNOBIKES.COM/SUPPORT/BOOST_POLY_WHEEL_GUARD
BOOST_POLY_WHEEL_GUARD_INSTALLATION_MANUAL_SEP23
COPYRIGHT 2022 BENNO® BIKES LLC

WARNING!

**REAR WHEEL MUST BE COVERED!
INSTALL PASSENGER ACCESSORIES
BEFORE CARRYING PASSENGERS!**

**FAILURE TO DO SO COULD
RESULT IN SERIOUS INJURY!**



MUST INSTALL

- RAIL or PASSENGER BAR
- RACK PADS
- WHEEL GUARDS or UTILITY PANNIER BAGS
- SIDELoader

WHEN CARRYING PASSENGERS, REAR WHEEL MUST BE COVERED! INSTALL BENNO WHEEL GUARDS OR UTILITY PANNIER BAGS, RAIL OR PASSENGER BAR, RACK PADS AND SIDELoader. FAILURE TO DO SO COULD RESULT IN SERIOUS INJURY! MAKE SURE THAT NO PARTS OF THE BODY OR CLOTHING COME NEAR MOVING PARTS ON THE BICYCLE, SUCH AS CHAIN, SPOKES, TIRES OR BRAKES. PASSENGERS MUST BE ABLE TO SECURELY HOLD THEMSELVES ON THE BIKE. DO NOT EXCEED TOTAL MAX GROSS WEIGHT OF THE BIKE AND/OR RACK MAX LOAD.